

Fire & Ice LED Tailgate Bar

INSTALLATION
INSTRUCTIONS



STEP 1:

Clean the area between your tailgate and bumper thoroughly with warm soap and water. The adhesive on the mounting pads of your LED Tailgate Bar will only work once, so the installation area must be free of dust, dirt, and rust, and must be **COMPLETELY DRY** before installation.

STEP 2:

Measure the width of your tailgate and determine the midpoint of this distance by dividing the length by 2. Mark this midpoint, then measure on either side of this mark, and mark the two new points as well to determine the left to right orientation of the LED Tailgate Bar to insure that it is centered.

STEP 3:

The bar is oriented properly on the truck if the wires are coming out of the left side and LEDs are pointing straight out the back. Peel the backing off all of the adhesive pads on the back of the Tailgate Bar and press it very gently onto the vehicle between the marks from Step 2. Step back from the vehicle and make sure the bar is mounted straight. Detach and reapply the pads if necessary to correct the placement.

STEP 4:


Once the LED Tailgate Bar is attached, simply plug in your 4-pin Trailer Hitch Connector. If your Trailer Hitch connector is being used by another product or a trailer, you can contact your Authorized PlasmaGlow Dealer or PlasmaGlow directly at 1-877-878-4569 to purchase a 4-way splitter for the Trailer Hitch Plug on your truck. This will allow you to hook up additional accessories to your truck.

If you do not have a Trailer Hitch Connector on your truck you will need to hard wire the Tailgate Bar into your truck's signal wires. You will need to cut the plug off the Tailgate bar and connect the wires into the signal system in your truck. See the diagram on the next page for hard-wiring instructions.

STEP 5:

REGISTER YOUR WARRANTY ONLINE OR BY SENDING THE ENCLOSED FORM! Your Warranty is not valid if you do not send in your Warranty Registration Form within 30 days! If you would like to request a PlasmaGlow Catalog with our new truck-specific lighting products, visit our website at www.plasmaglow.com

Tailgate Bar Hard-Wiring Instructions



1. Cut the 4-Pin Trailer Plug Adapter off of your LED Truck Bar, leaving enough wire to identify which wire went to which pin.

2. Connect the PIN 1 wire to any ground on the vehicle (such as the frame).

3. Connect the PIN 2 wire to a 12 Volt + (positive) wire that is live only when your brakes are pressed (such as your brake light).

4. Connect the PIN 3 wire to a 12 Volt + (positive) wire that is live only when your left turn signal is activated (such as your left turn signal light).

5. Connect the PIN 4 wire to a 12 Volt + (positive) wire that live only when your right turn signal is activated (such as your right turn signal light).

6. Connect the white wire to the + signal to your reverse lights

White Wire Connects to + Signal to Factory Reverse Lights

WARRANTY REGISTRATION
YOU CAN ALSO REGISTER YOU ONLINE AT
WWW.PLASMAGLOW.COM (CLICK THE WARRANTY LINK)

**Your warranty is not valid if your product is not registered within
30 days of purchase!**

Product: Fire & Ice LED Tailgate Bar

Name: _____

Address: _____

City: _____

State: _____ Zip Code: _____

Email: _____

Date of Purchase: _____

Store Name: _____

Price Paid (Excluding Tax): _____

Type of Vehicle: _____

Rate your satisfaction with this product (1-10) _____

Were the Instructions Easy to Follow: _____

Would you like us to mail you a catalog: _____

Why you purchased this product (Check All That Apply)

- | | |
|--|--|
| <input type="checkbox"/> Magazine Advertisement | <input type="checkbox"/> Store Recommendation |
| <input type="checkbox"/> Store Display | <input type="checkbox"/> PlasmaGlow Brand Name |
| <input type="checkbox"/> Catalog | <input type="checkbox"/> Warranty |
| <input type="checkbox"/> Friend's Recommendation | <input type="checkbox"/> Saw it at a Show |

Please keep your receipt in a safe place

It is required to make a Warranty Claim

Please mail this completed form to:

PlasmaGlow
Product Registration
PO Box 2564
Gilbert, AZ 85299

OR REGISTER ONLINE AT WWW.PLASMAGLOW.COM